

Materials Included:

- Fabric
 - Main Front and Back – 2 pieces 10 1/2" x 6"
 - Pocket Front and Back – 2 pieces 7" wide at top and 6" wide at the bottom, and 5" tall
- Fusible Fleece – one piece 10 1/2" x 6 and one piece 7" x 5"
- 1 Plastic Curtain Grommet
- 1 Grommet Template

To start, identify all your fabric and fleece pieces. Iron the fleece to the back side of one of the pocket pieces and one of the main pieces. I like to fuse it to the pieces that will be the front, it keeps everything looking nice. Trim away any excess fleece.

Sew the two pocket pieces together just along the top edge, with right sides together and a 1/4" seam allowances. Fold the pieces so the right sides are out and press.

Place the front pocket on the front main piece (the one with the fusible fleece on the back side) and line up the bottom edge and the sides. Sew the sides and bottom down with a 1/4" seam allowance. Because the top of the pocket is wider, the pocket will stick out from the main piece just a bit.

Use a spool of thread as a guide and trim all four corners so they are rounded.

Pin the back main piece to the front main piece so that the right sides are together. Sew around the sides and leave an 2" opening on the bottom. Turn the holder right side out through the opening then hand sew the opening closed.

Position the plastic curtain grommet template into place. Trace the slots and cut out hole. Place raised center of grommet in hole toward the back. On the back side, position the "prong" side of the grommet. Using the palm of your hand, press down to secure.

(Tip: To remove grommet, insert flat screwdriver tip into slot; lift up.)

If you prefer to have instructions, with pictures included, please visit my website and check out my tutorials!

www.sewmuchmoore.com

